

DI接线

飞线说明		西门子S7-300 (6ES7321-1BH02-0AA0)			西门子S7-300 (6ES7321-1BL00-0AA0)					
预接线线号	线号表示	端子号	端子号表示	飞线线号	端子号	端子号表示	飞线线号	端子号	端子号表示	飞线线号
1	0.0	1			1			21		
2	0.1	2	0.0	1	2	0.0	1	22	2.0	1
3	0.2	3	0.1	2	3	0.1	2	23	2.1	2
4	0.3	4	0.2	3	4	0.2	3	24	2.2	3
5	0.4	5	0.3	4	5	0.3	4	25	2.3	4
6	0.5	6	0.4	5	6	0.4	5	26	2.4	5
7	0.6	7	0.5	6	7	0.5	6	27	2.5	6
8	0.7	8	0.6	7	8	0.6	7	28	2.6	7
9	1.0	9	0.7	8	9	0.7	8	29	2.7	8
10	1.1	10	DC0V	19	10	DC0V	19	30	DC0V	19
11	1.2	11			11			31		
12	1.3	12	1.0	9	12	1.0	9	32	3.0	9
13	1.4	13	1.1	10	13	1.1	10	33	3.1	10
14	1.5	14	1.2	11	14	1.2	11	34	3.2	11
15	1.6	15	1.3	12	15	1.3	12	35	3.3	12
16	1.7	16	1.4	13	16	1.4	13	36	3.4	13
17	DC24V	17	1.5	14	17	1.5	14	37	3.5	14
18	DC24V	18	1.6	15	18	1.6	15	38	3.6	15
19	DC0V	19	1.7	16	19	1.7	16	39	3.7	16
20	DC0V	20	DC0V	20	20	DC0V	20	40	DC0V	20

D0接线

飞线说明		西门子S7-300 (6ES7322-1BH01-0AA0)			西门子S7-300 (6ES7322-1BL00-0AA0)					
预接线线号	线号表示	端子号	端子号表示	飞线线号	端子号	端子号表示	飞线线号	端子号	端子号表示	飞线线号
1	0.0	1	DC24V	17	1	DC24V	DC24V	21	DC24V	17
2	0.1	2	0.0	1	2	0.0	1	22	2.0	1
3	0.2	3	0.1	2	3	0.1	2	23	2.1	2
4	0.3	4	0.2	3	4	0.2	3	24	2.2	3
5	0.4	5	0.3	4	5	0.3	4	25	2.3	4
6	0.5	6	0.4	5	6	0.4	5	26	2.4	5
7	0.6	7	0.5	6	7	0.5	6	27	2.5	6
8	0.7	8	0.6	7	8	0.6	7	28	2.6	7
9	1.0	9	0.7	8	9	0.7	8	29	2.7	8
10	1.1	10	DC0V	19	10	DC0V	19	30	DC0V	19
11	1.2	11	DC24V	18	11	DC24V		31	DC24V	18
12	1.3	12	1.0	9	12	1.0	9	32	3.0	9
13	1.4	13	1.1	10	13	1.1	10	33	3.1	10
14	1.5	14	1.2	11	14	1.2	11	34	3.2	11
15	1.6	15	1.3	12	15	1.3	12	35	3.3	12
16	1.7	16	1.4	13	16	1.4	13	36	3.4	13
17	DC24V	17	1.5	14	17	1.5	14	37	3.5	14
18	DC24V	18	1.6	15	18	1.6	15	38	3.6	15
19	DC0V	19	1.7	16	19	1.7	16	39	3.7	16
20	DC0V	20	DC0V	20	20	DC0V	20	40	DC0V	20